

DENVER[®]

DVR-150 **DVD RECORDER**



DVD + ReWritable



Safety Precautions



The lightning flash with an arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



- WARNING:** DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE, DUE TO THE HIGH RISK OF FIRE OR ELECTRIC SHOCK, DO NOT OPEN THE CABINET DANGEROUS HIGH VOLTAGES ARE PRESENT INSIDE THE ENCLOSURE. ONLY QUALIFIED SERVICE PERSONNEL SHOULD ATTEMPT THIS.
- CAUTION:** TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, AND FULLY INSERT.
- ATTENTION:** POUR EVITER LES CHOCES ELECTRIQUE, INTRODUIRE LA LAME LARGE DE LA FICHE DANS LABORNE CORRESPONDANTE DE LAPRISE ET POUSSER JUSQU'AU FOND.
- CAUTION:** This Digital Video Player employs a Laser System. To prevent direct exposure to the laser beam, do not try to open the enclosure. Visible laser radiation emits when open and interlocks are defeated. Use of controls or adjustments or procedures of procedures other than those specified herein may result in hazardous radiation exposure.
DO NOT STARE INTO BEAM.

To ensure proper use of this product, please read this owner's manual carefully and retain for future reference. Should the unit require maintenance, contact an authorized service location. Only qualified service personnel should remove the cover.



CLASS 1
LASER PRODUCT

Since it is very usual for DVD movies to be released at different times in different regions of the world, all players have region codes and disks can have an optional region code. If you load a disk of a different region code to your player, you will see the region code notice on the screen. The disk will not play, and should be unloaded.

Safety Information

CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Please carefully study this manual and always keep it available. There are, however, some installation and operation precautions which you should be aware of.

1. Read Instructions - All the safety and operating instructions should be read before the product is operated.
2. Retain Instructions - The safety and operating instructions should be retained for future reference.
3. Heed Warnings - All warnings on the product and in the operating instructions should be adhered to.
4. Follow Instructions - All operating and use instructions should be followed.
5. Cleaning - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. Attachments - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
7. Water and Moisture - Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.
8. Accessories - Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
9. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.
10. Ventilation - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
11. Power Sources - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

12. Grounding or Polarization This product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

Alternate Warnings This product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

13. Power-Cord Protection Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

14. Protective Attachment Plug The product is equipped with an attachment plug having overload protection. This is a safety feature. See instruction Manual for replacement or resetting of protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug specified by the manufacturer that has the same overload protection as the original plug.

15. Outdoor Antenna Grounding - If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

16. Lightning - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and powerline surges.

17. Power Lines - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

18. Overloading - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

19. Object and Liquid Entry - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

20. Servicing - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

21. Damage Requiring Service - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:


- a. When the power-supply cord or plug is damaged.
- b. If liquid has been spilled, or objects have fallen into the product.
- c. If the product has been exposed to rain or water.
- d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- e. If the product has been dropped or damaged in any way, and
- f. When the product exhibits a distinct change in performance - this indicates a need for service.

22. Replacement Parts - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

23. Safety Check - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

24. Wall or Ceiling Mounting - The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

25. Heat - The product should be situated away from heat sources such as radiators, heat registers, stoves or other products (including amplifiers) that produce heat.



Introduction

Your DVR-150 Design combines the functionalities of a DVD player and recorder. As a DVD player, you will be able to enjoy full length movies with true cinema picture quality, and stereo or multichannel sound (depending on the disc and your playback system). Unique features of this player include Scart & S-video outputs for greater picture clarity.

What's more, as a DVD Video Recorder, it has some of the key features that allow you to record programs conveniently such as:

- A complete DVD+RW/DVD+R recorder.
- Preset recording
- Playback of pre-recorded or user-recorded DVDs and CDs
- View, edit and play from a pre-recorded DVD+RW.



UNPACKING

When shipping the player, the original shipping carton and packing comes in handy. For maximum protection, re-pack the unit as it was originally packed at the factory. It is normal for your changer tray to partially open after you have unpacked the unit. This is a feature designed to allow easier access to disc inside the tray during diagnostics.

First check and identify the contents of your player package, as listed below:

- DVR-150
- Remote control
- RCA cables (3) x2 (1 yellow, 1 red, and 1 white)
- Owner's manual

If any item should be damaged or missing, please inform your supplier without delay. Keep the packaging materials as you may need them to transport your player in the future.

WHERE TO PLACE YOUR DVD RECORDER

1. Place the unit on a firm, flat surface.
2. When you place this player near a radio or VCR the playback picture may become poor and/or distorted. In this situation, move the DVD video player away from the other units.
3. Keep away from direct sunlight & domestic heating equipment.
4. If placed in a cabinet, please allow at least 2.5 cm (1 inch) of free space around the player for proper ventilation.

TO OBTAIN A CLEAR PICTURE


This player is a high-tech, precision device. If the optical pick-up lens and disc drive parts are dirty or worn down, the picture quality will become poor. To obtain a clear picture, we recommend regular inspection and maintenance (i.e. cleaning or parts replacement) every 1,000 hours of use depending on the operating Environment. For details, please contact your nearest dealer.

Table of Contents

Safety Precautions.....	1	Using the On-screen Display.....	22
Safety Information.....	2	Setting the Parental Lock.....	23
Introduction.....	3	Customizing DVD Function Settings.....	24
Table of Contents.....	4	Recording Options.....	25
Identification of Controls.....	5	Channel Search.....	25
Connection.....	7	Normal Recording.....	25
MP3.....	11	One-Touch Record.....	26
Playing Back a Disc.....	12	Time Record.....	27
Playing a Normal Disc.....	12	Editing.....	28
Playing a DVD+RW or DVD+R Disc.....	13	Editing a Title of DVD+RW.....	28
General Features.....	13	Editing a Disc of DVD+RW or DVD+R.....	31
Locating a Specific Title,		Specifications.....	32
Chapter or Track.....	15	Trouble Shooting Guide.....	33
Playing Repeatedly.....	17		
Playing in Random Order.....	18		
Selecting Camera Angles, Languages			
& Audio Settings.....	19		
Playing in a favorite Order.....	20		
Selecting Subtitles.....	21		

Identification of Controls


FRONT PANEL



1. STANDBY/ON
2. OPEN/CLOSE
3. RECORD
4. PLAY
5. STOP
6. SOURCE

7. Digital Vidicon INPUT
8. AUDIO INPUT (FRONT LEFT)
9. AUDIO INPUT (FRONT RIGHT)
10. COMPOSITE VIDEO INPUT (FRONT)
11. S-VIDEO INPUT (FRONT)

REAR PANEL



1. RF SIGNAL INPUT
2. RF SIGNAL OUTPUT
3. COMPOSITE VIDEO INPUT (REAR)
4. S-VIDEO INPUT
5. AUDIO INPUT (REAR LEFT/RIGHT)
6. AUDIO OUTPUT (MIXED)


7. 5.1CH AUDIO OUTPUT
8. COMPOSITE VIDEO OUTPUT
9. S-VIDEO OUTPUT (REAR)
10. DIGITAL AUDIO-COAXIAL OUTPUT
11. DIGITAL AUDIO-OPTICAL OUTPUT
12. SCART OUTPUT
13. COMPONENT OUTPUT

Identification of Contrls

REMOTE CONTROL

THE INSTRUCTIONS BELOW DESCRIBE THE FUNCTIONS OF THE REMOTE CONTROL

1. OPEN/CLOSE
2. DV
3. TV
4. NUMBERS
5. SETUP
6. DIRECTION
(UP/DOWN/LEFT/RIGHT)
7. SELECT
8. MENU
9. TIMER
10. REC/OTR
(RECORD/ONE-TOUCH RECORD)
11. PLAY
12. STOP
13. REVERSE
14. PREVIOUS
15. FWD
16. NEXT
17. AUDIO
18. SUBTITLE
19. REPEAT
20. SLOW
21. PROG
22. RANDOM
23. STANDBY/ON
24. SCAN
25. AV(SOURCE)
26. NAVIGATION
27. ADD/CLEAR
28. TITLE
29. DISCOPER
30. EDIT
31. MUTE
32. PAUSE/STEP
33. VOLUME+
34. CHANNEL+
35. VOLUME-
36. CHANNEL-
37. RETURN
38. ANGEL
39. DISPLAY
40. ZOOM
41. GOTO
42. PS/IS(PROGRE SSIVE / INTERLACE SCAN)




Connection

CONNECTION FOR AUDIO OUTPUT


Dolby Pro Logic Surround Sound (GOOD)

Enjoy Dolby Pro Logic Surround by connecting an amplifier and speaker system (right and left front speakers, a center speaker, and one or two rear speakers).



Enjoying Digital Stereo Sound (BETTER)


Enjoy the dynamic sound of Digital Stereo by connecting an amplifier equipped with a digital audio input and speaker system (right and left front speakers, a center speaker, and one subwoofer speaker, and two rear speakers)




Connection

CONNECTION FOR VIDEO OUTPUT

GOOD




BETTER




Connect your recorder with the S-Video cable, if the TV has an S-Video input. Do not connect the yellow video cable of using the S-Video cable.

SCART RGB VIDEO OUTPUT (BEST)

The SCART Video OUTPUTput allows you to enjoy the best picture quality from a DVD video disc.



CONNECTION FOR TV TUNER




NOTE

- Refer to the manual of the connected TV.
- Turn off the power and unplug both units before setting up any connections.

Connection

THE DVR-1000 ALLOWS YOU TO ENJOY OR RECORD PROGRAMS WITH SIGNAL FROM AV SYSTEMS SUCH AS VCR, DVD PLAYER, ETC.

CONNECTION FOR AV SIGNAL (A/V REAR INPUT)




Connect your recorder with the S-Video cable, if the Signal Source has an S-Video input. Do not connect the yellow video cable if using the S-Video cable.

NOTE

- Refer to the manual of the connected system.
- Turn off the power and unplug both units before setting up any connections.

Connection

CONNECTION FOR AV SIGNAL (A/V FRONT INPUT)



NOTE

- Refer to the manual of the connected system.
- Turn off the power and unplug both units before setting up any connections.

MP3 & Progressive Scan

WHAT IS MP3?

MP3 refers to a new format of music files available for playback over the internet. The popularity of MP3 allows people to download music from MP3 websites onto their home computer.

WHAT IS PROGRESSIVE SCAN?

Progressive Scan creates a picture with double the scan lines of traditional component video pictures and creates a sharper image. The advantages of progressive scan video output are reduced picture flickering and motion artifacts as well as a sharper image on large screens.



Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1992-1997 Dolby Laboratories, Inc. all rights reserved.


Playing Back a Disc

PLAYING A NORMAL DISC

1. Power on your recorder.

2. Insert a DVD disc.


3. Press direction Keys or the number buttons to select the title.



4. Press the **SELECT** or **PLAY** button.



The DVD video player will start playback from the title selected.

5. To remove the disc, press the **OPEN/CLOSE** button.



PLAYING A DVD+RW OR DVD+R DISC

Index Picture Screen



Description:

1. The name of the pre-recorded. The default is TITLE.
2. The date and time of the record.
3. Title time of the record.
4. The quality.
5. Length of the record

1. TITLE
2. 01/01/00
3. 12:03:47
4. SP 00:00:20
5. _____

Playing Back a Disc

PLAYING A DVD+RW OR DVD+R DISC

1. Power on your recorder.

2. Insert a DVD+RW or DVD+R disc

The index pictures will appear on the screen.

3. Press the OPEN/CLOSE button

This will open the disc tray and allow for the placement of a playable disc with the playback side down.

4. Use direction keys (UP/DOWN/RIGHT/LEFT) to highlight the item you desired.

5. Press SELECT or PLAY to start playback of the title you selected.


6. Stop playback

Press the STOP button once to stop the player; press the **PLAY** button to resume playing.

To playback from the start, press the **STOP** button twice then press the **PLAY** button.

Note:

After finishing playback of all titles contained on a DVD+RW or DVD+R disc, it will return to the Index Picture Screen.



GENERAL FEATURES

All playback operation can be realized by the navigation. During playback, press DISPLAY button twice to access the control bar:

▶ DVD	
MODE	Normal ▶
TRICK	Play
TITLE	35/41
CHAPTER	01/01
AUDIO	01/02-OTH
SUBTITLE	Off
ANGLE	01/01
T-TIME	00:00:00-00:00:00

The details of every functions see below:

Press RIGHT/LEFT to highlight one icon and press SELECT to enter it, press UP/DOWN to select a item, press SELECT.

Press DISPLAY again to cancel the control bar.

MODE Normal ▶

Playback mode Set your preferable playback mode such as PROGRAM, RANDOM and various repeat mode.

TRICK Play

Playback control Control playback by various setting such as FAST FORWARD, FAST REVERSE, PAUSE, STOP, etc.

TITLE 35/41

Title Select to choose an available title by inputting numbers.

CHAPTER 01/01

Chapter Select to choose an Available chapter by inputting numbers.

AUDIO 01/02-OTH

Audio Select your desired audio setting, if Available.

SUBTITLE Off

Subtitle Select to choose an available subtitle by inputting Numbers.

ANGLE 01/01

Angle Select your desired camera angle, if Available.

T-TIME 00:00:00-00:00:00

Timer Goto the point you want to start from by inputting the time.

Playing Back a Disc

GENERAL FEATURES

1. Fast forward playback

Press ► during normal playback.

The speed will cycle with each press as: FF2, FF4, FF16, FF32 or play.

Press **PLAY** to resume normal playback.

2. Fast reverse playback

Press ◀ during normal playback.

The speed will cycle with each press as: FB2, FB4, FB16, FB32 or play.

Press **PLAY** to resume normal playback.

3. Pause playback

Press PAUSE/STEP during normal playback to pause playback and press **PLAY** to resume normal playback.

4. Frame advance

Press **PAUSE/STEP** during normal playback.

One frame is advanced each time you press **PAUSE/STEP**.

Press **PLAY** to resume normal playback.


5. Slow

Press the **SLOW** button during playback

The playback speed becomes 1/2, 1/4, 1/8 of the normal speed or normal play each time you press the SLOW button.


Note:

The above features vary depending on the disc type such as MP3, Audio CD, etc.



Locating a Specific Title, Chapter or Track


DVD VIDEO DISCS ARE NORMALLY DIVIDED INTO TITLES AND SUB-DIVIDED INTO CHAPTERS. SIMILARLY, CD'S(AUDIO, HDCD, and MP3) ARE DIVIDED INTO TRACKS. YOU CAN CONVENIENTLY LOCATE ANY SPECIFIC TITLE, CHAPTER, OR TRACK WITH THIS DVD PLAYER.



LOCATING A TITLE USING THE TITLE MENU

You can locate a specific title using the title menu function, if a DVD video disc contains a title menu.

1. Press the **TITLE** button
On the TV screen, the title menu will appear.
2. Press the **▲/▼/◀/▶** button to select the title you want
3. Press the **SELECT** button
This will cause the DVD video player to start playback from chapter 1 of the title selected.



NOTICE

- There are some disc that does not respond to this function.
- If different instructions appear on the TV screen, follow those instructions. The instructions above are describe the basic procedure, but procedures may vary depending on the contents of the DVD video disc.

LOCATING A SPECIFIC CHAPTER OR TRACK

This player allows you to locate consecutive chapters or tracks.

Press the SKIP ◀◀ or ▶▶ button repeatedly to display the requested chapter or track

The player starts playback from the selected chapter or track.

PREV NEXT
◀◀ ▶▶

How to locate proceeding chapters or tracks

- When you press the **SKIP ◀◀** button, the player starts playback from the beginning of the preceding chapter or track.

How to locate succeeding chapters or tracks

- When you press the **SKIP ▶▶** button, the player starts playback from the beginning of the succeeding chapter or track..

Notice: on some discs the titles may not display the sub-divided chapters.

Locating a Specific Title, Chapter or Track

LOCATING A TITLE

If a DVD video disc contains title numbers, you can locate a specific title by directly selecting a title number.

1.Press GOTO during playback.

The control bar will display on the screen.

▶ CHAPTER---


► TITLE:--

▶ TIME-: --:--

2. To select your desired Chapter, input the number of a available chapter, then press SELECT to confirm it.

e.g. To select Chapter2

► CHAPTER- -2



3. To select your desired title, press GOTO to highlight the icon and input the number of a available title, then press SELECT.

► TITLE:--

4.If you want to start playback from some point, press GOTO to highlight the icon

► TIME: --:-- ,and input the time, then press SELECT.

Note:



- The function is invalid on MP3 disc.
- For CD disc, GOTO is used for track/time selection.

Playing Repeatedly

THIS RECORDER ALL ALLOWS YOU TO PLAYBACK A SPECIFIC TITLE, CHAPTER, TRACK, OR SEGMENT REPEATEDLY.(TITLE REPEAT, CHAPTER/TRACK REPEAT,A-B REPEAT)

HOW TO REPEAT A TITLE, CHAPTER, OR TRACK

1. Press the **REPEAT** button during playback.
The repeat mode changes, each time you press the **REPEAT** Button.



HOW TO REPEAT A SPECIFIC SEGMENT

1. Press **DISPLAY** button twice to access the control bar.
2. Highlight **MODE Normal** ► by pressing **RIGHT/LEFT**, press **SELECT**.
3. Use **UP/DOWN** to select **A-B Repeat** and press **SELECT** at the beginning of the segment in which you want to repeat playback(point A).

4. Press **SELECT** again at the end of the segment(point B)

The player will automatically return to point A and Start to repeat playback to the selected segment(A-B)

5. Highlight **MODE A-B Repeat** ► by pressing **RIGHT/LEFT**, press **SELECT**.
Use **UP/DOWN** to select **NORMAL** and press **SELECT** to resume normal playback.

Note:

- There are two repeat modes for MP3/CD disc. On CD disc, they are track repeat and disc repeat, and on MP3 disc, they are repeat song and repeat directory.


► DVD		
MODE	Normal	Normal
TRICK	Play	A-B Repeat
TITLE	35/41	Chapter Repeat
CHAPTER	01/01	Title-Repeat
AUDIO	01/02-OTH	Disc Repeat
SUBTITLE	Off	
ANGLE	01/01	
T-TIME	00:00:00-00:00:00	

Playing in Random Order


THIS RECORDER ALLOWS YOU TO PLAYBACK TITLES, CHAPTERS WITHIN A TITLE, OR TRACKS IN RANDOM ORDER.

PLAYING TITLES IN RANDOM ORDER

1. During normal playback press the RANDAM button.
The player will start random playback now.



2. Press RANDOM again to resume normal playback.




Note:

- The player will go to another chapter or track and start playback, if you press the SKIP button ,  , during random playback.

Selecting Camera Angles, Languages & Audio Settings

THIS RECORDER ALLOWS YOU TO SELECT FROM SEVERAL DIFFERENT ANGLES AND LANGUAGES.



▶ AUDIO :01/03 GER DOLBY

▶ AUDIO :02/03 ENG DOLBY

▶ AUDIO :03/03 CHI DOLBY


Selecting a language

HOW TO CHANGE THE CAMERA ANGLE

If the video on the DVD was recorded with multiple angles, you have the option to change the camera angle of the scene you are watching.

Press the ANGLE button while playing back a scene recorded with multiple angles.

- You may only press the ANGLE button when the angle icon ▶ ANGEL :01/03 is shown on the DVD display.
- Each time you press the ANGLE button, the angle will change.




Note:

- The angle function will not work on DVD video discs that does not contains recorded multiple angles.
- During still playback, you are able to change the camera angle. When you resume to normal playback, the camera angle changes to the new settings.
- The angle icon indicator will illuminate while playing back a title that contains at least one scene recorded from multiple angles.

HOW TO SELECT A LANGUAGE & PLAYBACK AUDIO SETTING

This player allows you to select a preferred language and sound recording system from those included on the DVD video disc.

1. Press the AUDIO button during playback
2. Press the AUDIO button repeatedly to cycle through the options



Note:

- The player returns to the initial default settings when you turn on the player or replace a disc.
- The player plays a default sound when unsupported format is selected.
- On MP3/CD disc, AUDIO is used for the selection of LEFT, RIGHT and STEREO.

Playing in a Favorite Order

THIS PLAYER ALLOWS YOU TO PROGRAM UP TO 99 ITEMS INTO MEMORY AND THEN PLAY THEM BACK IN THAT ORDER. (PROGRAM/PLAYBACK)


HOW TO SET TITLES, CHAPTERS, OR TRACKS IN A FAVORITE ORDER

1. Press **DISPLAY** button twice to access the control bar.

2. Highlight **MODE** Normal ◀ by pressing **RIGHT/LEFT**, press **SELECT**.

3. Use **UP/DOWN** to select **PROGRAM** and press **SELECT**, two volumes will appear on the screen.

- The left volume displays all titles available on the disc.



- The right volume allows you to edit titles in your favorite order.

2. In the left volume, use **UP/DOWN** to select one title, and press **ADD/CLEAR** to add it to the right volume.

You can also select one chapter by pressing **SELECT** after highlighting the title.

3. To clear one title you have added in the right volume, highlight the one and then press **ADD/CLEAR** to clear it. Use **RIGHT/LEFT** to move the cursor between the volumes.


4. Press **PROG** to return the **PROGRAM** play back.

5. Press **DISCPLAY** button twice to access the control bar

Select **MODE** Program ▶ use **UP/DOWN** to select **NORMAL** and press **SELECT** to resume normal playback.


Note:

- On the MP3/CD disc, there are some difference on OSD.





Selecting Subtitles

THIS RECORDER ALLOWS YOU TO DISPLAY THE SUBTITLES FROM THOSE INCLUDED ON THE DISC ON TO YOUR TV SCREEN.



HOW TO DISPLAY SUBTITLES

Press the SUBTITLE button during playback to choose one of the subtitle available on the disc, or turn the subtitle off.



Note:

- Due to the nature of some DVD's, you may not be able to turn off the subtitles as they will appear on screen automatically.
- As you press the SUBTITLE button, the subtitles may not appear immediately during some scenes.
- If the subtitles continue to show on your TV even after the DVD has been turned off, please check the closed caption settings on your TV.

Using the On-Screen Display

THIS PLAYER ALLOWS YOU TO VIEW STATUS AND DISC INFORMATION ON YOUR TV SCREEN.

CHECKING THE OPERATIONAL STATUS

With this function, you can view on your TV the following information:

- Play back status
- Current title
- Current chapter
- Current language
- Current title Time

Press DISPLAY button during DVD playback.

► Normal Play T01/25 C06/21 AU01/03 00:26:48

→ PLAYBACK STATUS

► Normal Play T01/25 C06/21 AU01/03 00:26:48

→ CURRENT TITLE/TOTAL TITLE

► Normal Play T01/25 C06/21 AU01/03 00:26:48


→ CURRENT CHAPTER/TOTAL CHAPTER

► Normal Play T01/25 C06/21 AU01/03 00:26:48

→ CURRENT LANGUAGE

► Normal Play T01/25 C06/21 AU01/03 00:26:48

→ CURRENT TITLE TIME




DISPLAY

Setting the Parental Lock

YOU CAN USE THE PARENTAL LOCK FUNCTION ONLY WITH DVD'S EQUIPPED WITH THE PARENTAL LOCK FEATURE

SETTING THE PARENTAL LOCK

DVD equipped with the parental lock function are rated according to their content. The contents allowed by a parental lock level and the way a DVD can be controlled may vary from disc to disc. For example, if the disc allows it, you could edit out violent scenes unsuitable for children and replace them with more suitable scenes, or lock out playback of the disc all together.




1. Press STOP button twice during playback.

2. Press SETUP during stop status.

3. Highlight the PLAY icon by pressing RIGHT/LEFT.

The menu appears on the TV screen.




4. Use UP/DOWN to select Rating Level, press SELECT button.

5. Input your password by numbers, highlight OK and press SELECT.

The pre-set password is 3308

6. Press SELECT, the sub-menu of Set Rating Level appears, use UP/DOWN to select one rating, press SELECT to confirm it.



7. Highlight OK and press SELECT to save your setting.


8. Press SETUP button to exit setup, press PLAY button to start

TO CHANGE YOUR PASSWORD:

1. Follow step 1-6 to select "New".
2. Enter new password.
3. Re-enter to confirm your new password.
5. Highlight OK and press SELECT to save it.
6. Press SETUP button to exit.

Customizing Function Settings

THIS PLAYER ALLOWS YOU TO CUSTOMIZE THE PERFORMANCE TO YOUR PERSONAL PREFERENCES.



DISPLAYING THE SETUP MENU SCREEN

The SETUP MENU screen asks you to select a setting category from General, Speaker, Audio and Preferences. The selected category will provide you the setting details using the succeeding screen.

Main Page		
GENGERAL	General Setup	
	screen saver	On/Off
	Scart output	CVBS/RGB
	Video output format	PAL/NTSC
	Restore factory settings	OK
PLAYBACK	Playback Setup	
	TV aspect ratio	16:9/Pan Scan/Letter box
	Rating level	Off
	Digital audio output	RAM/LPCM
	Closed captions	ON/OFF
RECORD	Record Setup	
	Audio chapter market	On/Off
	Default source	F-CS/ F-SV/ RE-CS / RE-SV/ DV/TUNER
	Default quality	SLP/EP/SP/HQ
LANGUAGE	Language Setup	
	OSD language	English/Spanish/.....
	Menu language	English/Chinese/...../Original
	Subtle language	Off/English/Chinese/...../Original
	Audio language	English/Chinese/...../Original
CHANNEL SCAN	Deltails see page 25	
CLOCK	Date& Time Setup	
	Date(mm/dd/yy)	01/01/00
	Time(hh:mm:ss)	01:15:01

1. Press **SETUP** during stop status.

2. Press direction keys (UP/DOWN/RIGHT/LEFT) to select category (highlight), then press **SELECT**.

3. Press **SETUP** to exit the setup menu.

Recording Options

CHANNEL SEARCH

To record TV programs, you should search TV channels first.

1. Press **SCAN** to access the TV setup menu.

2. Use the **UP/DOWN** button to highlight **SCAN** and press **SELECT**.



It will search channels automatically.
During auto-searching, press **STOP** to cancel searching.

3. To browse the found channels, use the **UP/DOWN** button to highlight **EDIT** and press **SELECT** to setup it, press **UP/DOWN** to Name, and you can also input numbers and press **SELECT**. In the **SKIP** column, The channel cannot be found will be "YES".

4. If you want to skip one channel, select the corresponding channel. use **UP/DOWN** button to highlight the skip and press **SELECT**, press **UP/DOWN** to highlight the yes, and press **SELECT**,

5. use **UP/DOWN** to highlight the **OK** and press **SELECT**.

6. Press **SETUP** again to exit.



SETUP RECORD QUALITY

1. Press **SETUP** during stop status.
2. Press direction keys (**UP/DOWN/R**) to select.
3. Select default quality.

HQ: Perfect quality, nearly 60 minutes in a blank disc

SP: Standard play quality, nearly 120 minutes in a blank disc

EP: Extend play, nearly 240 minutes in a blank disc

SLP: Standard long play, nearly 360 minutes in a blank disc

NORMAL RECORDING

1. Make connections illustrated as page 8 -10.

2. Insert a recordable **DVD+RW** or **DVD+R** into the recorder.

3. Press **DV**, **TV** or **AV** to select the input source which you have connected as step 1.

F-A/V: Front Audio/Video Input (on the front panel)

R-A/V: Rear Audio/Video Input (on the rear panel)

F-SV: Front S-Video (on the front panel)

R-SV: Rear S-Video (on the rear panel)

TV: (you can select it by pressing **CHANNEL +/-** or input the assigned number of the channel to select your desired one directly)

DV: Digital vidicon

4. Press **RECORD** to start recording.

If you want to stop recording, press **STOP**.

If the **DVD+RW** or **DVD+R** is new, it will take about three minutes to stop.

ONE-TOUCH RECORD


1. During normal recording, press **RECORD**, the recorder will auto stop in 30 minutes.
2. The record time will extend for another 30 minutes with each press.
The length of recording time is determined by disc capacity and record quality.
With your setting, if it will exceed the capacity of the disc, OTR will be canceled, and switched to normal record.
3. If you want to stop recording, press **STOP**.

HOW TO SWITCH TO PLAYBACK MODE

When the recording is suspended, you can press **PLAY** to switch to normal playback mode.

CLOCK SETUP

1. During stop status, press **SETUP** to access the Setup Menu.
2. Use **RIGHT/LEFT** to highlight the **CLOCK** icon as the right figure.
3. With “Date (mm/dd/yy)” highlighted, press **SELECT**, and input the local date by numbers, press **SELECT** again.
4. With “Time (hh:mm:ss)” highlighted, press **SELECT**, and input the local time by numbers, press **SELECT** again.



Note:

If you want to cancel input, press **RETURN**.

Recording Options


TIMER RECORD

1.First setup the clock of your system as “CLOCK SETUP” on page 26.

It is recommended to setup your local date and time.

2.Press TIMER, the record scheduler will pop up.

Record scheduler						
	Source	Quality	Date	Start	End	
(W)	1	DV	SP	12/01/03	14:41	15:11
(W)	2	Rear CVBS	SP	DAILY	07:03	08:33
(W)	3	Ch057	HQ	12/31/03	12:44	13:05
	4					
	5					
	6					



Note:

- If you want to delete a scheule, highlight the one, press ADD/CLEAR.

2.Use UP/DOWN to select one schedule, and press SELECT to access Item Editor as below:
In each item you can also use direction keys to highlight and press SELECT to choose your desired setting:

Signal input source, details see page 25,step 3.

Record frequency, once, daily or weekly.

Mm/dd/yy

Start time for timer recording

End time for timer recording

Record quality, details see

page 25 setup record quality.

Item Editor	
Sorce	DV
ONCE	0 1/0 1 /0 0
Start	1 4 : 4 1
End	1 5 : 1 1
Quality	SP
Confirm Cancel	

3.Select Confirm to save your setting.

4.In five minutes before it is ready to record the scheduled, it appears a Record Prompt dialog, affirm press Confirm, abolish press CANCEL, and if without operation for a moment it will record the scheduled automatically.

Note:

- In standby mode, your recorder can wake up in 2 minutes before recording.
- During recording, you can press STOP to suspend the recording.
- ADVD+RW/DVD+R can record for upto 360 minutes.


EDITING A TITLE OF DVD+RW

1.Insert a recorded DVD+RW on the disc tray.
The Index Picture screen pops up.

2.Use the direction keys to highlight the title which you want to edit.

3.Press EDIT, the edit bar appears on the screen while playing back.


Press RIGHT/LEFT to highlight one icon and enter it, press UP/DOWN to select a sub-item.



View current title/total title




View current chapter/total chapter




Current operation status




Chapter editing Select to add one chapter, or delete the current/all chapters, details see the next page.



Chapter hide or unhide Select to hide the current page chapter,, details see the next page




Title face or Title name Select to set the current image played back to the face of the title or select to name the current title, details see the next page.



Divide current to 2 titles at current point




Title Timer



4.Press EDIT to quit the menu.

CHAPTER EDITING

From the control bar, select the fourth icon, press **SELECT** repeatedly, it will cycle as following:



When **Insert marker** is selected by pressing **SELECT**, a new chapter marker will be added to the current point.

When **Delete marker** is selected by pressing **SELECT**, the marker of the current chapter will be deleted.

When **Delete all markers** is selected by pressing **SELECT**, all of the chapter markers will be deleted.

Note:

From the second icon in the control bar, the above operation can be viewed.

If only one chapter is available in the current title, there is only **Insert marker** to select.

CHAPTER HIDE OR UNHIDE

From the control bar, select the fifth icon, press **SELECT**.

When the icon displays  **Hide chapter**, it shows the current chapter is visible, and you can select it to hide it by pressing **SELECT**.

When the icon displays  **Unhide chapter**, it shows the current chapter is invisible, and you can select it to unhide it by pressing **SELECT**.

TITLE ICON AND SPLIT TITLE

From the control bar, select the sixth icon, press **SELECT** .

When you want to set the current frame as the icon of the current title which miniature picture will appear in the Index Picture Screen, Press **SELECT** with  Index picture displayed.

From the control bar, select the seventh icon, press **SELECT** .

When  Split title is selected by pressing **SELECT**, a new title marker will be added to the current point.

EDIT TITLE NAME

1.Insert a recorded DVD+RW on the disc tray.

The Index Picture screen pops up.

2.Use the direction keys to highlight the title which you want to edit.

3.Press RIGHT, the edit bar appears on the screen while playing back.

Press UP/DOWN to highlight one icon and **SELECT** it.

4.From the control bar, select the fourth icon, press **SELECT .**

On the screen, there appears a keyboard:

Play title
Erase title
Edit title
Rename title
Overwrite title
Overwrite disc

 Title name

TITLE_

A	B	C	D	E	F	G	H	I	J	K	0	1	2
L	M	N	O	P	Q	R	S	T	U	V	3	4	5
W	X	Y	Z	(	)	-	:	?	.	6	7	8	9
Space	Caps	BkSp	Delete	Clear	Exit	OK							

Press the direction keys (UP/DOWN/RIGHT/LEFT) to highlight the one which you want to input, and press **SELECT** to confirm it.

The control bars of the last line in the keyboard is for edit command.

Select **OK** to save the name.

Note:

The maximum length of the title name is up to 9 characters.

EDITING A DISC OF A DVD+RW

1. Insert a DVD+RW on the disc tray.
2. Press DISC OPER to access the disc editing menu.
3. With each icon highlighted by pressing UP/DOWN, the corresponding description of each operation will display on the screen, such as Erase disc, Rename disc, Record a new title, Overwrite disc, etc.
4. Press SELECT to run the operation.

Play
Erase disc
Rename disc
Make compatible
Record a new title
Overwrite disc
Lock disc
Finalize disc

EDITING A DISC OF A DVD+RW OR DVD+R

Play

Press SELECT to playback from the disc.

Erase disc

ERASE (only DVD+RW)

Press SELECT to begin erasing.

Rename disc

Press the direction keys (UP/DOWN/RIGHT/LEFT) to highlight the one which you want to input, and press SELECT to confirm it.

The control bars of the last line in the keyboard is for edit command. Select OK to save the name.

Note:

The maximum length of the title name is up to 9 characters.

↳ Disc name

W_

A	B	C	D	E	F	G	H	I	J	K	0	1	2
L	M	N	O	P	Q	R	S	T	U	V	3	4	5
W	X	Y	Z	()	-	:	?	·	6	7	8	9	
Space	Caps	BkSp	Delete	Clear	Exit	OK							

Make compatible

compatible(only DVD+RW)

It shows you can make your current disc compatible. If you want to make your disc compatible with the other DVD player. You should go on COMPATIBLE operation.

Lock disc

LOCK(only DVD+RW)

When the icon display LOCK, it shows you can lock your current disc. If you have locked Your disc, you can't make any changes any more except play it back, but you can unlock it by UNLOCK.

Finalize disc

Finalize(only DVD+R)

Highlight the icon and press SELECT. It will take a few minutes to finalize the disc.

Note:

If a DVD+R has been finalized, you can not record or edit DVD+R any more. If you want to make your disc compatible with the other DVD player, you should go on FINALIZE operation.

Specifications

DVD Player

TV System	NTSC/PAL
Compatible Discs	DVD+R, DVD, CD, Mp3, DVD+RW, CD-R, CD-RW
Recordable discs format	DVD+RW, DVR-R
Resolution Ratio	Greater Than 500 lines
Video S/N Ratio	65dB
Frequency Response	fs (96KHz/24bit) 4Hz - 44KHz: +/-2dB
Audio S/N Ratio	95dB
Degree of Distortion	<0.01%
D/A Converter	192KHz/24bit
Video Out	1Vp-p
S-Video Out	Y: 1Vp-p(75Ω) C: 0.3Vp-p(75Ω);
Audio Out	2.0V 5.1 Channel, 2 Channel mixed
Digital Audio Output	Optical, Coaxial
Connections	YUV, SCART, CVBS S-Video

Remote Control

Transmitter	Infrared Ray
Signal Range	Approximately 15'
Power Source	2 "AAA" Batteries

General

Power Supply	AC 95~240V 50/60Hz
Consumed Power	30W
Standby Power	<3W
Size (WxHxD)	

Because its products are subject to continuous improvement, We reserves the right to modify product design and/or specifications without notice and without incurring any obligations.

SYMPTOMS AND CORRECTION

Symptom	Correction
No power	Connect the power plug into the wall outlet securely.
No picture	- Verify the connection from the DVD video output to the TV video input. Then Switch TV to appropriate mode(video 1) - Connect the videocable into thejacks securely. Refer to your television owners manual.
No sound	- Connect the audio cables into thejacks securely. - Verify the connection from the DVD audio output to the TV or receiver audio input. Then switch to the appropriate source on the receiver. Refer to your Audio amplifier owners manual.
Black & White picture	Damaged S connector(bent pin)
The playback picture Has occasional distortion	- A small amount of picture distortion may appear because of a poor quality video/sound transfer to disc. This is especially true of some discs Manufactured between 1997-1998. - Scratched disc
Brightness is unstable or noises are produced on playback pictures	- Connect the DVD player directly through the TV and not through any other source. What you're viewing is the effect of the copy protection circuitry Required on all DVD players. - If you don't have a video input on your TV, you must purchase an Therefore Adapter from your dealer.
The DVD video player does not start playback	- Place the disc with the graphics side up. - Place the disc on the disc tray correctly inside the guide. - Make sure the disc is free from scratches & fingerprints. - Press the SETUP button to turn off the menu screen. - Cancel the parental lock function or change the parental lock level. (The Pre-set password is 3308.) - Turn the power off then disconnect the power plug and reinsert it back into the wall. Retry again. - Use region 1 discs only.
MP3 won't read disc or It skips	- Return disc as the software edition used may not be compatible with the player. Check web site for instruction. - Use new editions of software such as Voyetra Audiostation 4, Adaptec's "Easy CD Creator", NTI or Roxio's Toast Titanium. - Make sure MP3 file are not encoded with a variable bit rate such as provided by Real Networks.
The remote control does not work Properly	Replace the batteries with new ones.
The recorder cannot record.	- The type of the disc is wrong, it's not a DVD+RW or DVD-R disc. - The disc is recorded full. - The disc (DVD+R, DVD+RW) is locked, it should be unlocked. - The DVD+R has been finalized.
Some keys do not work	- The type of the disc is wrong, it's not a DVD+RW or DVD-R disc. - The unit is in record mode or it is recording.
The image is distorted.	- The setup of interlaced or Progressive is wrong. - Press the I/P button to switch from each other.



Manufactured under license from Dolby Laboratories. "Dolby",
"Pro Logic" and the double-D symbol are trademarks of Dolby
Laboratories. Confidential Unpublished Works. ©1992-1997
Dolby Laboratories, Inc. all rights reserved.